Why To prevent grease build-up and to meet McDonald's cleanliness standards

Time required 5 minutes to prepare 45 minutes to complete

Time of day End of work day For 24-hour restaurants: Late night or early morning when volume is low

Hazard icons

Chemicals

Chemicals

Hot Liquids/Steam

Hot Oil

Hot Surfaces

Manual Handling Sharp Objects/Surfaces Slippery Floors

### Tools and supplies













Putty Knife

HI-lo Deck Brush

#### **Procedure**

1 Power switch off
Make sure the main power
switch is in the OFF position.



2 Remove grease trap Remove grease trough and cup in hood and pour contents into oil disposal shuttle



3 Release casters Release the locks on the fryer casters.



4 Cover fryer vats
Place vat covers on all vats.






5 Roll fryer from hood Carefully roll the fryer from the hood far enough to get behind the fryer.





Caution: Hot cooking oil may splash when moving the fryer.





Remove filters
Remove grease filters and
take to back sink to soak in
hot McDonald's A.P.C.
(HCS)




8 Clean hood
Use a putty knife to carefully clear grease from the hood and behind the fryer.
continued >



# Clean Behind Fryer (continued)

# 9 Cleaning Order Clean the area behind the fryer in this sequence:

- A. Accessible parts of stack
- B. Back of hood
- C. Sides of hood
- D. Grease filter recess
- E. Sheet metal around fryer





### 11 Scrub

Use a nylon brush and hot McD A.P.C. (HCS) to clean areas behind fryer, including the floor.



# 12 Towel dry

Wipe all areas with a towel until clean and dry. Have manager inspect.



#### 13 Wash casters

Use nylon brush and hot McD A.P.C. (HCS) to clean casters.



# 14 Clean Area

Use a mop and McD A.P.C. (HCS) to clean area around fryer.



## 15 Return fryer

Reverse steps 1 - 7 to return fryer to hood and replace grease filters. Remove vat covers.



# Mot Oil

Caution: Hot cooking oil may splash when moving the fryer.

# 16 Clean filter drain pan

Wipe the oil and crumbs from the drain pan. Clean the drain pan with soap and water, then thoroughly rinse with hot water.

