

**Why** To keep oil from leaking from tube

**Time required** 5 minutes to examine and replace if necessary

**Time of day** Anytime the fryer is not filtering

**Hazard icons**  Hot Oil  Hot Surfaces  Moving Parts  Slippery Floors

### Tools and supplies



Flat-head screwdriver

### Procedure

- 1 Pull-out filter drain pan**  
Open the door, depress the drain pan stop release and pull the filter drain pan assembly out, using the handle on the drain pan.



**Hot Surfaces**

This pan could be hot! Use protective cloth or glove, or severe burns could result.



- 2 Check o-rings**  
Visually check the o-rings on the tube of the filter drain pan for any cracks or breaks and replace if necessary.



- 3 Replacing o-rings**  
Using a small, flat-bladed screwdriver, pry up on the o-ring and pull off of end of tube. Roll new o-ring into notch on tube.

